

# Quick Start Guide



---

4-inch Linux Visible Light Terminal

Version: 1.1



# Overview

## SpeedFace-V4LM1



**Note:** Features and parameters with ★ mark are not available in all devices.

## SpeedFace-V4L



**Note:** This manual only take **SpeedFace-V4LM1** as an example for detailed introduction, and the functions of **SpeedFace-V4L** will not be repeated.

## Installation Environment


Please refer to the following recommendations for installation.



INSTALL INDOORS  
ONLY



AVOID INSTALLATION  
NEAR  
GLASS WINDOWS




AVOID DIRECT  
SUNLIGHT  
AND EXPOSURE



AVOID USE OF ANY  
HEAT SOURCE  
NEAR THE DEVICE

## Recommended Palm Gestures★



KEEP EFFECTIVE  
DISTANCE OF  
30-50 cm



KEEP SPACES  
BETWEEN  
YOUR FINGERS



DO NOT KEEP  
YOUR FINGERS  
CLOSE



DO NOT KEEP  
PALM OUTSIDE  
COLLECTION AREA



DO NOT KEEP  
YOUR FINGERS  
FOLD/CURLED

### Note:

1. Place your palm within **30-50 cm** of the device.
2. Place your palm in the palm collection area, such that the palm is placed parallel to the device.
3. Make sure to keep space between your fingers.


## Recommended Standing Position



KEEP EFFECTIVE  
DISTANCE OF  
0.3-2m




## Device Installation




- ① Attach the mounting template sticker to the wall, and drill holes according to the mounting paper. Fix the back plate on the wall using wall mounting screws.
- ② Attach the device to the back plate.
- ③ Fasten the device to the back plate with a security screw.

## Standalone Installation




## Power Connection



### Recommended power supply

- 1)  $12V \pm 10\%$ , at least 3000mA.
- 2) To share the power with other devices, use a power supply with higher current ratings.

## Ethernet Connection




Click [COMM.] > [Ethernet] > [IP Address], input the IP address and click [OK].

**Note:** In LAN, IP addresses of the server (PC) and the device must be in the same network segment when connecting to ZKBioAccess IVS software.


## Lock Relay Connection

The system supports both **Normally Opened Lock** and **Normally Closed Lock**. The **NO Lock** (normally opened when powered) is connected with 'NO1' and 'COM' terminals, and the **NC Lock** (normally closed when powered) is connected with 'NC1' and 'COM' terminals. The power can be shared with the lock or can be used separately for the lock, as shown in the example with NC Lock below:




1) Device not sharing power with the lock



2) Device sharing power with the lock





## Door Sensor, Exit Button & Alarm Connection





## Wiegand Reader Connection

Wiegand card reader connects to the top 4 pins of the wiegand terminal and the last two pins are used by the Access Controller, as shown in the following figure. It sends the credentials to the device via wiegand communication.



## RS485 Connection

The RS485 lets user connect to multiple readers to the device. RS485 can be connected to the terminal, as shown in the figure below.





# User Registration


When there is no super administrator set in the device, click on ☰ to enter the menu. Add a new user and set User Role to Super Admin, then the system will request for the administrator's verification before entering the menu. It is recommended to register a super administrator initially for security purposes.

## Method 1: Register on the device

Click on ☰ > [User Mgt.] > [New User] to register a new user. The options include entering the user ID and Name, setting User Role, registering Palm<sup>★</sup>, Face, Card Number, Password and adding User Photo.




New User	
User ID	1
Name	Mike
User Role	Normal User
Palm	1
Face	1
Card Number	1
Password	*****
User Photo	1
Access Control Role	



## Method 2: Register on ZKBioAccess IVS software

Please set the IP address and cloud service server address in the Comm. Menu option on the device.

1. Click **[Access] > [Access Device] > [Device] > [Search Device]** to search the device on the software. When an appropriate server address and port is set on the device, the searched devices are displayed automatically.




2. Click **[Add]** in operation column, a new window will pop-up. Select Icon type, Area, and Add to Level from each dropdowns and click **[OK]** to add the device.
3. Click **[Personnel] > [Person] > [New]** and fill in all the required fields to register a new users in the software.
4. Click **[Access] > [Device] > [Device Control] > [Synchronize All Data to Devices]** to synchronize all the data to the device including the new users.

For more details, please refer to the ZKBioAccess IVS User Manual.


### Method 3: Register on the phone

Once the ZKBioAccess IVS software is installed, the users could enroll their face via a browser application on their own mobile phone.



1. Click **[Personnel]** > **[Parameters]**, input "http://Server address: Port" in the QR Code UGL bar. The software will automatically generate a QR code. Scan the QR code or login onto "http://Server address: Port/app/v1/adreg" by the mobile phone to register users.







2. The users will be displayed in **[Personnel]** > **[Temporary Personnel]**, click on **[Review]** option and assign a department and click **[OK]** to successfully add the user.



# Ethernet and Cloud Server Settings

Click on  > [COMM.] > [Ethernet] to set the network parameters. If the TCP/IP communication of the device is successful, the icon  will be displayed in the upper right corner of the standby interface.

Click on  > [COMM.] > [Cloud Server Setting] to set the server address and server port, that is, the IP address and port number of the server after the software is installed. If the device communicates with the server successfully, the icon  will be displayed in the upper right corner of the standby interface.



## Note:

While pairing the device with ZKBioAccess IVS software. Make sure that the option **Enable Domain Name** is disabled and the correct server address and port are entered.

**Server Address:** Set as the IP address of the ZKBioAccess IVS server.




**Server Port:** Set as the service port of ZKBioAccess IVS (the default is 8088).



# Detection Management Settings



Click on ☰ > [System] > [Detection Management] to enter the setting interface.

- 1 You can enable mask detection function, and enable the **Deny access without mask** and the **Trigger external alarm**, the device will send an alarm prompt when the user doesn't wear a mask, meanwhile the user will be forbidden to access, as shown in the following figure.
- 2 When the **Allow unregistered people to access** is enabled, optionally, set **Enable capture of unregistered person** to save the user photo.






## Connect to ZSmart

After downloading and installing the ZSmart App on the phone, open the App and add the device by scanning the QR code. Click [System] > [Video intercom parameters] > [QR code binding] on the device to enter the QR code interface. The process is as follows:





## Video Door Phone Connection

Visitors press the doorbell button on the device to make a call and the phone will ring. The user can accept or decline the call. After the user accepts the call, it will open the video door phone interface. Enter the password to unlock the door.




# Access Control Setting

Click on ☰ > [Access Control] to enter the access control management interface and set relevant parameters of access control.



# Attendance Record

Click on ☰ > [Attendance Search] > [Event Logs] to enter the logs query interface, input the user ID and select the time range, the corresponding event logs will be displayed.



Personal Record Search

Date	User ID	Time
03.03		
Number of Records:04		
4		11:25
2		11:25 11:22
3		11:25
03.04		
Number of Records:04		
1		11:29
3		11:29 11:21
2		11:28
4		11:28
03.05		
Number of Records:04		
1		11:27
4		11:27
3		11:27
2		11:27

ZKTeco Industrial Park, No. 32, Industrial Road,  
Tangxia Town, Dongguan, China.

Phone : +86 769 - 82109991

Fax : +86 755 - 89602394

[www.zkteco.com](http://www.zkteco.com)

